

Shared Logging Setup — Supabase (free database)

Goal: Reece, Samantha, and you all see the same logged workouts. ~15 minutes, one-time.

STEP 1 — Create a free Supabase account

1. Go to supabase.com → click "Start your project" → sign up (GitHub or email).
2. Click "New project". Give it any name (e.g. "hyrox-walker"). Set a database password — write it down somewhere, you likely won't need it again but just in case.
3. Choose any region close to you. Click "Create new project". Wait ~2 minutes while it sets up.

STEP 2 — Create the storage table

1. In the left sidebar, click the **SQL Editor** icon (looks like ">_").
2. Click "New query". Paste this exactly, then click **Run** (or press Cmd/Ctrl+Enter):

```
create table kv_store ( key text primary key, value text not null, updated_at timestampz default now() ); alter table kv_store enable row level security; create policy "public read" on kv_store for select using (true); create policy "public write" on kv_store for insert with check (true); create policy "public update" on kv_store for update using (true);
```

3. You should see "Success. No rows returned." That means the table is ready.

Note: this makes the table publicly readable/writable by anyone with your project URL — fine for a private family training app, not for sensitive data.

STEP 3 — Get your two keys

1. In the left sidebar, click the gear icon (**Project Settings**) → **API**.
2. Copy the **Project URL** (looks like <https://abcdefgh.supabase.co>).
3. Copy the **anon public** key (a long string starting with "eyJ...").

You'll paste both into the app code in the next step — keep this tab open.

STEP 4 — Paste the keys into the app

1. Open `hyrox-trainer/src/HyroxTrainer.jsx` in a text editor.
2. Near the top, find these two lines:

```
const SUPABASE_URL = "YOUR_SUPABASE_URL"; const SUPABASE_ANON_KEY = "YOUR_SUPABASE_ANON_KEY";
```

3. Replace the placeholder text (keeping the quotes) with your real values from Step 3.
4. Save the file.

STEP 5 — Deploy

In Terminal, make sure you're inside the `hyrox-trainer` folder (type `pwd` to check — it should end in `/hyrox-trainer`), then run:

```
vercel --prod
```

Same URL as before goes live with shared logging. Reece, Samantha, and you now all see the same data — no re-saving the home screen icon needed.

Troubleshooting

- Logs still don't show across phones → double check both keys were pasted exactly, with no extra spaces, and that you ran `vercel --prod` after saving.
- Want to see the raw data yourself? In Supabase, click **Table Editor** → `kv_store`. Every log, note, and setting is a row there.
- Supabase free tier is generous (500MB, well beyond what this app needs) and doesn't expire for active projects.